



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

TABLE OF CONTENTS

GENERAL INFORMATION 2

INITIAL SETUP 3

PLUGIN CONTROLS (Setup) 4

PLUGIN CONTROLS (Presets) 6

PLUGIN CONTROLS (Channels) 7

KNOWN ISSUES 8

ADDITIONAL INFORMATION 8



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

GENERAL INFORMATION	
Q-SYS PLUGIN NAME	Shure Audio Network Interface (ANI)
VERSION	1.0
AUTHORED BY	Control Concepts, Inc.
SUMMARY	Use this Q-SYS plugin to control Shure Audio Network Interface (ANI) devices in Q-SYS Designer. Monitor and update network information and other device settings. Settings include gain, mute behavior, and channel information.
GENERAL NOTES	This plugin is designed to support the following models: • ANI4IN • ANI4OUT • ANI22
DEVICE USED FOR TESTING	Q-SYS Core 110f (v9.10.0)



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

INITIAL SETUP

PROPERTIES	Model: Select the model the plugin will connect to. Valid models are: • ANI4IN [Default] • ANI4OUT • ANI22 Meter Update Rate (ms): Set the rate for metering updates. Default is 500ms. Valid values are 100-10000. It is recommended to keep this value at 500ms or slower. Debug Level: Indicates the specificity level of messages that appear in the debug window. The options include: 1-<i>Off</i>: No messages will be printed. [Default] 2-<i>Device Communication</i>: Only messages related to commands going to/coming from physical devices will be printed. 3-<i>Troubleshooting</i>: All internal messages will be printed. Log Debug Messages: Indicates whether to also save any messages that are printed to the debug window to the internal Q-SYS processor's logs. [Default: False]
ESTABLISHING CONNECTION	This plugin has three ways of establishing a connection: 1. During design time, set up your programming to input the IP address and port information of your device. Device will connect automatically. 2. During run time, select the device to connect to from the auto-discovery dropdown box. The plugin can only discover devices on the local network. 3. During run time, keep the auto-discovery dropdown selection on "Manual" and enter the IP address and port into the fields provided on the plugin. All methods of connecting will persist through reboots and design pushes.



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

PLUGIN CONTROLS (Setup)

Auto-Discovery	Provides a list of "Manual" and discovered Shure devices on the local network that match the model of this plugin. Each discovered device will only show if the model matches the model type of the plugin. Select a device from the dropdown menu to connect and control. <i>[Both String]</i>
Manual-Entry IP Address	If Auto-Discovery is set to "Manual" this address will be used for device connection. <i>[Both String]</i>
Port	Set the port the plugin will use to connect to the device. <i>[Both String]</i>
Status	Indicates that the plugin status. <i>[Output String]</i>
Is Communicating	Indicates that the plugin established a connection with the device. <i>[Output Boolean]</i>
Is Initialized	Indicates that the plugin has synced all states from the device. <i>[Output Boolean]</i>
Control Network IP Address	Reports the IP address of the device connected. <i>[Output String]</i>
Control Network MAC Address	Reports the MAC address of the device connected. <i>[Output String]</i>
Control Network Web Link Access	Reports the address the device can be connected to in a browser. <i>[Output String]</i>
Audio Network IP Address	Indicates the audio network IP address. <i>[Output String]</i>
Audio Network Subnet Mask	Indicates the audio network subnet mask. <i>[Output String]</i>



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

Audio Network Gateway	Indicates the audio network gateway. <i>[Output String]</i>
Dante Device Name	Indicates the Dante device name. <i>[Output String]</i>
Control Network Device Name	Indicates the control network device name. <i>[Output String]</i>
Device Model	Indicates the model. <i>[Output String]</i>
Serial Number	Indicates the serial number. <i>[Output String]</i>
Firmware	Indicates the firmware version. <i>[Output String]</i>
Reboot Device	Triggers a device reboot. <i>[Input Boolean]</i>
Device Mute	Toggles the device mute and reflects the current state. <i>[Both Boolean]</i>
Identify	Flashes device status LEDs and reflects the current state. <i>[Both Boolean]</i>
Brightness Level	Set the brightness of the LED on the device. Valid values are: • Disabled • Dim • Default <i>[Both String]</i>



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

PLUGIN CONTROLS (Presets)

Preset # Name	Indicates the name of the associated preset number. <i>[Output String]</i>
Preset # Recall	Trigger to recall the associated preset number. <i>[Output Boolean]</i>



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

PLUGIN CONTROLS (Channels)

Channel Name	Indicates the current channel name. Read only. <i>[Output String]</i>
Channel Gain Fader	Controls the gain of the channel and reports the current gain. Valid values are -18 to 42. <i>[Both Number]</i>
Channel Gain Text	Controls the gain of the channel and reports the current gain in dB. Valid values are -18 to 42. <i>[Both String]</i>
Channel Gain Increase	Trigger to increase the channel gain by 1 dB. <i>[Input Boolean]</i>
Channel Gain Decrease	Trigger to decrease the channel gain by 1 dB. <i>[Input Boolean]</i>
Channel Meter	When metering is enabled, this reports the RMS meter of this channel. <i>[Output Number]</i>
Channel Mute	Toggles channel mute and reports the current mute state. <i>[Both Boolean]</i>



Manufacturer: Shure
Model: Audio Network Interface (ANI)
Device Type: AudioIO

KNOWN ISSUES

No known issues.

ADDITIONAL INFORMATION

Change Log	v1.0 – Initial Release
Support	Company: Shure Email: support@shure.com